

HOISTING THE LIFT TRUCK

- Never lift up by the overhead guard.
- Before lifting-up, Check that the mounting bolts of mast and counterbalance-weight are tightened to the specified torque.
 - Tightening torque for the counterbalance-weight mount bolts : 441 - 639Nm {45 - 65kgfm}
 - Tightening torque for the mast lower mount bolts
 - : 157 - 196Nm {16 - 20kgfm} (AX50 Series)
 - : 343 - 427Nm {35 - 43kgfm} (BX50 Series)
- To hoist the lift truck, hook on the holes on the top of the outer mast for the front, and the hole on the top of the counterbalance-weight for the rear.
- Do not go under the lifted truck.
- Use undamaged wire having sufficient strength. For the hoisting of lift truck, see "4.12 HOISTING LIFT TRUCK (PAGE 4-46)".
- If the lift truck has to be lifted frequently, it is necessary to install special lifting equipment, so please contact your FORKLIFT distributor.

CAUTION WHEN HOISTING THE LIFT TRUCK

